

Resene product labels are updated from time to time. This label is provided as a guide for this product and may differ from the label on the container you purchase. Please discuss your project with your local Resene ColorShop team or reseller to ensure you have the right products to give you the best quality finish for your specific project.

# Resene

**SpaceCote Clear**  
waterborne low sheen  
interior

KEEP OUT OF REACH OF CHILDREN



**CLEAR**

LL1479001F 5/18

net contents 1 litre  
tinter included LL1479001B 5/18

#### SAFETY PRECAUTIONS

Read label before use. Keep out of reach of children. This material is quite bland; with vapour, occasional skin contact and even minor ingestion having negligible hazard. Repeated skin contact may, and any eye contact will, cause irritation. Harmful to aquatic life.

#### PRECAUTIONS

Store in original or correctly labelled container, tightly closed, in a well ventilated area indoors, away from foodstuffs, at an ambient temperature and avoid freezing conditions. Avoid release to the environment.

#### FIRST AID

IF SWALLOWED: Immediately call a POISON CENTRE, doctor, physician or first aider.

IF ON SKIN (or hair): Rinse skin with plenty of soap and water. If skin irritation or rash occurs get medical advice or attention.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do so. Continue rinsing. If eye irritation persists get medical attention or advice.

IF INHALED: If breathing is difficult, remove to fresh air and keep at rest in a position comfortable for breathing.

If exposed or concerned get medical advice or attention.

If medical advice is required have product container or label at hand.

Further information can be obtained from  
AUST: POISONS INFORMATION CENTRE 1311 2266  
or call Resene 1800 738 383.

NZ: NATIONAL POISONS CENTRE 0800 POISON  
(764 766) or call Resene 0800 737 363.

For use as a decorative/protective coating.  
For full technical instructions see Data Sheet D513.

**SPILLS:** Wear appropriate clothing. Absorb with sand or earth. Collect and seal in properly labelled drums. Do not allow to enter drains or to run off into waterways. Refer to local waste management authority.

#### CLEANING PAINT EQUIPMENT:

Brush/roll out as much paint as possible onto newspaper before washing brushes and rollers. Dispose of wash-up water onto grassy/unsealed area or into inside sink/basin, NOT into outside stormwater drain where it may harm fish in local waterways.

Resene SpaceCote Clear is a low sheen clear finish, designed to bring enamel style toughness to broadwall areas, allowing you to get a low sheen finish without sacrificing durability. Ideal to protect interior wall paints and Mason wallpaper. A durable low odour finish with scuff, scrub and burnish resistance.

#### Preparation

- Ensure substrates to be coated are in sound condition, dry, free from dirt, dust, loose material, curing and release membranes, oil and salt.
- If mould is present, treat with Resene Moss & Mould Killer (see Data Sheet D80).
- Ensure wallpaper is clean and free from any powdery materials.
- **All sanding dusts may be harmful and appropriate protection must be worn. In particular dusts from old lead or chromate based paints or old building materials containing asbestos may be injurious to health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.**
- This product may be used to paint a wide variety of surfaces. If the surface you propose to paint is unsound or not referred to, try a small test area first or contact your local Resene ColorShop or Reseller for advice.

#### Application

- Do not shake contents, rather stir well with a wide flat stirrer.
- Wallpaper – first test on a small area to ensure that the finished appearance is as desired and that there is no reaction with wallpaper inks. While it can be used on other wallpapers, the plasticiser in some vinyl wallpapers can make topcoats feel sticky to touch. Always trial in an inconspicuous area first and leave for two weeks before coating all wallpaper.
- Do not brush or roll excessively to avoid excess foaming of the material. Lay-off with care.
- Do not apply in direct sunlight.
- Maintain good ventilation throughout the drying and post application curing period to ensure the paint is properly cured. This may require use of an extraction system when painting in marginal painting conditions. Do not use gas or diesel burners to heat coated area as these produce water that will inhibit drying and curing. Poor ventilation may affect appearance and performance.

#### Bathrooms/ensuites/steamy areas

Steam and condensation can cause surfactants in a new paint film to come to the surface as shiny streaks. This does not harm the paint. To ensure your bathroom/ensuite paint finish keeps looking its best: For the first 5-7 showers wipe steam moisture from walls using a lint free cloth immediately after showering. This will prevent the moisture on your freshly painted walls bringing surfactants to the surface. If any marks appear use Resene Interior Paintwork Cleaner, following the instructions in the Resene Caring for your paint finish brochure.

#### Maintenance (after a minimum of four weeks' drying)

See the Resene Caring for your paint finish brochure or the Resene website for full cleaning instructions.

- When cleaning use a soft sponge with luke warm water and a small amount of liquid detergent.

#### Be PaintWise

For tips on responsible disposal of paint, cleaning equipment and minimising the impact of your decorating on the environment see the Resene website. Do not discharge any paint into the environment. Resene PaintWise (NZ) or paintback.com.au (Australia) accepts residual unwanted paint and packaging. Or contact your Local Authority for disposal information.

## Quick check

**Use on:** Paint finishes and Mason wallpaper.

**Gloss level:** Low sheen.

**Coverage:** 11 square metres per litre per coat.

**Dry time (minimum):** Touch dry 45 minutes. Do not apply at temperatures below 10°C or when temperatures are liable to drop below this during the drying period. Drying is slowed by low temperatures and high humidity. Do not apply under damp conditions.

**Recoat time (minimum):** 2 hours.

**Usual number of coats:** Two.

**Application method:** Brush, speed brush, roller or spray.

**Thinning:** In hot conditions may be thinned with up to 5% Resene Hot Weather Additive to slow drying.

**Clean up:** Water.

**Colour range:** Milky – dries clear.

**Before use:** Stir well with a wide flat stirrer.

Enjoy the Resene Promise of quality on premium paints. See your Resene ColorShop or the Resene website for a copy. In every case it is recommended that the appropriate Data Sheet and Safety Data Sheet are consulted prior to application.

Please ensure that use of this product is compatible with the substrate and surface preparation method. Resene does not accept any responsibility for the application of incorrect product to substrate or the application of incorrect colours. For further painting advice and information, call 1800 738 383 (AUST), 0800 737 363 (NZ) or visit the Resene website.

# Resene

the paint the professionals use

In Australia: Resene Paints (Aust) Limited  
7 Production Ave, PO Box 924, Beenleigh, QLD 4207  
Ph 1800 738 383 Visit [www.resene.com.au](http://www.resene.com.au)

In New Zealand: Resene Paints Limited  
Vogel St, PO Box 38242, Wgtn Mail Centre, Lower Hutt 5045  
Ph (04) 577 0500 Visit [www.resene.co.nz](http://www.resene.co.nz)

Manufactured under a quality system certified as complying with ISO9001 by Telarc SAI, an accredited certification body. Printed on environmentally responsible paper, which meets with the requirements of environmental management system EMAS. Printed using de-inkable toners for recycling with no solvent emissions.