

Resene SpaceCote Low Sheen

waterborne enamel

Resene SpaceCote Low Sheen is the result of long, careful, intensive research. This breakthrough product may be used to bring enamel style toughness to broadwall areas, allowing you to get a low sheen finish without sacrificing durability.

So adaptable that it may also be used on joinery and trim, both inside and out.

interior

Typical uses

- Architraves
- Bathrooms
- Furniture
- Kitchens
- Laundries
- Plywood
- Timber doors
- Wallboards
- Window frames

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.

Vehicle type
Pigmentation
Solvent
Finish
Colour

Physical properties

New generation acrylic
Titanium dioxide
Water
Low sheen
Selected Resene Total Colour System, including BS5252, Multi-Finish, Whites & Neutrals and The Range.

Dry time (minimum)
Recoat time (minimum)
Serviceable within

45 minutes at 18°C
2 hours
12-48 hours depending on film thickness, tinter levels and drying conditions

Primer required
Theoretical coverage
Dry film thickness

Yes
11 sq. metres per litre
37 microns at 11 sq. metres per litre

Usual no. of coats
Abrasion resistance
Chemical resistance

2
Very good
Fair

Heat resistance
Solvent resistance

Good
Good

Durability
Thinning

Excellent
In hot dry conditions may be thinned with up to 5% Resene Hot Weather Additive to slow drying

Clean up
VOC

Water
c. 55 grams per litre (see [Resene VOC Summary](#))

Performance

Performance and limitations

1. Reduced side sheen minimises the appearance of minor surface defects.
2. Very durable, abrasion resistant finish that may be easily cleaned. Ideal for GIB® ToughZone® areas.
3. Non-yellowing.
4. May be used wherever solventborne enamels have traditionally been used.
5. Resene SpaceCote Low Sheen may be applied over Resene Quick Dry (see [Data Sheet D45](#)) or directly over sound, clean old enamel surfaces.
6. Clean, spatter free application.
7. An Environmental Choice approved product.

Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. Ensure the correct primers and/or sealers are used.
3. Due to waxes used in fibre and particle board it is essential that Resene Quick Dry (see [Data Sheet D45](#)) is used as the first coat on these substrates.
4. Although serviceable within 12-48 hours, full print and solvent resistance takes 30 days to develop.



SpaceCote Low Sheen waterborne enamel

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould.

If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)). Sand to smooth finish and dust off. Old enamels require fine sanding to a uniform dull finish.

Prime as per the following:

Fibrous plaster, paperfaced plasterboard

Resene Broadwall Waterborne Wallboard Sealer (see [Data Sheet D403](#)). Ensure new paperfaced plasterboard is prepared to a level of finish suitable for the specified paint finish. Resene Broadwall Surface Prep & Seal (see [Data Sheet D807](#)) or Resene Broadwall 3 in 1 (see [Data Sheet D810](#)) will be required to achieve a level 5 finish.

Particle board, timber

Resene Quick Dry (see [Data Sheet D45](#)). (Where a staining type of timber exists an application of Resene Wood Primer (see [Data Sheet D40](#)) may be required).

Soft or absorbent surfaces

Where the surface to be painted is considered too soft to form a stable substrate, a saturation coat of a fully penetrating sealer such as Resene Sureseal (see [Data Sheet D42](#)) may be required.

Varnished surfaces, laminated surfaces

Resene Waterborne Smooth Surface Sealer (see [Data Sheet D47a](#)).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, speed brush, synthetic fibre roller (Resene No.1) or spray. Thin with up to 5% Resene Hot Weather Additive in hot, dry conditions to slow drying.

New

1. Prepare and prime as above.
2. Apply two coats of Resene SpaceCote Low Sheen in required colour allowing at least two hours between coats.

Repaint

1. Prepare surface and spot prime as above.
2. Apply two coats of Resene SpaceCote Low Sheen in required colour allowing at least two hours between coats.

Precautions

1. Ensure the correct primer and/or sealer is used.
2. Stop all nailholes and cracked timber after priming.
3. Allow putty to thoroughly harden before painting.
4. Allow Resene SpaceCote Low Sheen sufficient drying before putting into full service.
5. Serviceable within 12-48 hours depending on film thickness, tinter level and drying conditions.
6. Resene Sureseal (see [Data Sheet D42](#)) must be used where paperfaced plasterboard has yellowed due to prolonged exposure to sunlight, and in wet areas, such as kitchens, bathrooms and laundries.



SpaceCote Low Sheen SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.